

## Dual Steering Column Pod for 2003-2009 Dodge Ram



1. Clean the area on the steering column with an alcohol prep pad and let it dry.
  2. Carefully line up and secure the steering column gauge pod to the steering column using the pre-applied double-sided tape. Be sure that the hazard switch and shift lever boot are clear.
  3. Follow the installation instructions that came with your gauge.
  4. Run the sensor and power wires to the gauge location and connect to the gauge.
  5. Check for leaks and test the operation of the gauge.
- This steering column pod will work with a manual transmission but there will be a cutout where the automatic shift lever boot is intended to be.
  - The Gauge Bracket that is included with the gauge does not have enough clearance in the gauge pod. Therefore, the gauge sits in the pod as a friction fit, or silicone can be applied from the backside.
  - GlowShift Gauges, LLC cannot guarantee the gauge fitment of other manufacturers.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.