

2015-2018 MINI Cooper Hardtop & 2016-2018 MINI Cooper Convertible Dashboard Pod Installation Instructions

1. Using a panel removal tool, carefully remove the center speaker grill mesh on the dashboard.
2. Remove the radio trim by depressing the retaining clips on the edge of the trim below the radio. Carefully remove this trim and set aside.
3. Using a t20 Torx bit, remove the two radio screws and set the radio aside.
4. You should now have access to the inside of the dashboard to properly route the gauge wires for installation. Connect the gauge wires to the power and sensor wires as per the instructions that are included with your gauge.
5. After, we recommend cleaning the area you are mounting this pod with an alcohol prep pad.
6. Then, secure the pod to the mounting location using the included double-sided tape.
7. Finally, reinstall the radio and dashboard trim. Test your new gauge for full functionality.

