

## Single Gauge Dashboard Pod for 2005-2013 Chevrolet Corvette



1. Carefully remove the gauge cluster surround by releasing the spring clips using a panel pop tool.
2. Unplug the connectors for the ignition, information center, heads-up display and the dimmer using a flat blade screwdriver.
3. Line up the dash pod on the left side of the gauge cluster surround. It will go around the heads-up display function switches. Mark a location to drill a hole under the gauge pod to pass the wiring through.
4. Clean the area on the cluster surround with an alcohol prep pad and let it dry.
5. Carefully line up and secure the gauge pod to the cluster surround using the pre-applied double-sided tape. Be sure that all the buttons for the heads-up display are clear and can be pressed freely.
6. Follow the installation instructions that came with your gauge.
7. Run the sensor and power wires to the gauge location and connect to the gauge.
8. Reinstall the cluster surround into the vehicle, making sure not to pinch any of the wires.
9. Check for leaks and test the operation of the gauge.

**NOTE:** The Gauge Bracket that is included with the gauge does not have enough clearance in the gauge pod. Therefore, the gauge sits in the pod as a friction fit, or silicone can be applied from the backside..

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.