

**Dash Gauge Pod Mounting Instructions for 1986-1993 Dodge Ram**

1. Remove the factory trim surrounding the vehicle's gauges using a Philips head screwdriver.
2. Place the pod on the dash (as indicated in the photograph).
  - Mark a location under the pod where you prefer to drill a hole that allows the gauge wires to pass through.
  - Use a ½" to ¾" drill bit depending on the amount of wires that have to pass through.
3. Connect the 2 1/16" [52mm] gauge wires to their sensors and power by following the instructions that are included with the gauges.
4. Before mounting the dash pod, route all the power and sensor wires and/or lines through the drilled hole. Be sure to have the wires and/or lines secured with wire ties to keep away from any moving parts inside the dash.
5. Place the pod onto the dash and, using the supplied self-tapping screws, secure the pod assembly to the dash. Make sure that the screw is installed at the correct angle in order to effectively secure it into the dash.
  - The 3" screw is used on the right side of the dash pod.
  - The 1 ½" screw is used on the left side of the dash pod.
6. Reinstall the factory dash trim after the pod has been installed.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.