

## Dashboard Gauge Pod for 2004-2006 GTO



1. Release the spring clips that are securing on the factory dash trim in the center of the dash using a panel pop tool and remove.
2. Route your gauge signal wires as well as the power and ground wires up through the dash to the opening.
3. **OPTIONAL STEP** : Our dash pod can be painted using ABS plastic paint. Be sure to scuff the surface of the pod using a scuff pad. This will allow the paint to properly adhere to the surface of the pod. Before applying paint to the pillar pod, ensure it is clean and that there is no residue on the pod from scuffing it. Apply 2-3 even coats, waiting 10 minutes between coats to dry.
  - Be sure to follow the paint manufacturer's instructions while painting, as well as proper safety procedures.
  - Be advised, you will not be eligible to return this pod for a refund if painted.
4. Slide the gauges into the dash pod.
5. Connect the 2 1/16" [52mm] gauge wires to their sensors and power by following the instructions included with the gauges.
6. Clean the area of the factory trim above the vents and front edge of the pod with alcohol.
7. Apply the included double-sided tape to the pod.
8. Slide the rear alignment tab into the factory trim and press firmly down on the gauge pod.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.