

2010-2013 Volkswagen Golf MK6 Vent Pod Installation Instructions



1. Remove the fuse panel cover located on the LH side of the dash using a panel removal tool.
2. Four spring clips are holding your air vent in place; two on the top and two on bottom.
3. Working through the end of the dash, push up on the spring clips on the lower portion of the vent housing, then, gently push outwards until the housing is removed from the dash.
4. Next, slide the 52mm adapter around the body of the gauge. If you are installing a 60mm gauge, this adapter will not be required.
 - **Note:** Adjustments to this adapter may be necessary by using sandpaper or a file to allow the ring to slide all the way up the gauge
5. Then, slide the gauge and adapter ring into the vent pod.
6. After, connect the gauge wires to the power and sensor wires as per the instructions that are included with your gauges.
7. Finally, slide the vent pod into the dashboard and test your newly installed gauge for functionality.