

Triple Pillar Gauge Pod for 1982-1993 Chevy S-10 /GMC Sonoma



Note: This pillar pod is a complete replacement and will require removal of the factory A-pillar trim if applicable. Be sure to store the factory A-pillar trim in a safe location when done.

1. Carefully remove the factory A-pillar trim by removing the 2 Phillips head screws.
2. **▶ OPTIONAL STEP** : Our pillar pods can be painted using ABS plastic paint. Be sure to scuff the surface of the pod using a scuff pad. This will allow the paint to properly adhere to the surface of the pod. Before applying paint to the pillar pod, ensure it is cleaned off and that there is no residue on the pod from scuffing it. Apply 2-3 even coats, waiting 10 minutes between coats to dry.
 - Be sure to follow the paint manufacturer's instructions while painting, including safety procedures.
 - Please be advised, you will not be eligible to return this pod for a refund if painted.
3. Install your gauges into the pod by following the instructions that are included with them.
4. Connect the gauge wires to their sensors and power as per the instructions included with the gauges.
5. Place the new gauge pod in position and secure using the supplied Phillips head screw using the top factory mounting location.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.