

Gauge Pillar Pod Mounting Instructions for 2014-2019 Chevrolet/GMC Full Size Truck

- 1. ⚠WARNING:** Prior to installing this pillar pod, make sure your vehicle does not have side curtain airbags.
- This pillar pod is a complete replacement and will require removal of the factory A-pillar trim. Be sure to store the factory A-pillar trim in a safe location when done.
 - Partially remove the weather stripping surrounding the factory A-Pillar.
 - Remove the factory A-pillar trim by releasing the spring clip and sliding it out of the way. There is a spring clip that is tethered on the middle location which has to be unclipped once the pod is loose.
 - If you have a grab handle, remove the factory A-pillar trim by removing the bolt covers using a flathead screwdriver; use a 10mm socket wrench to remove the bolts.
 - Insert the supplied plastic clip (as indicated by the arrow in the photograph) into the upper oval hole of the A-Pillar support where the spring clip was secured
- OPTIONAL STEP:** Our pillar pods can be painted using ABS plastic paint. Be sure to scuff the surface of the pod using a scuff pad. This will allow the paint to properly adhere to the surface of the pod. Before applying paint to the pillar pod, ensure it is cleaned off and that there is no residue on the pod from scuffing it. Apply 2-3 even coats, waiting 10 minutes between coats to dry.
 - Be sure to follow the paint manufacturer's instructions while painting, as well as proper safety procedures.
 - Be advised, you will not be eligible to return this pod for a refund if painted.
- Connect the 2 1/16" [52mm] gauge wires to their sensors and power by following the instructions that are included with the gauges.
- Install the pillar pod to the factory A-pillar support using the included screw. This screw installs through the predrilled hole on the pod into the plastic clip that was installed in Step 2.
 - To ensure a proper fit, thread the included screw into the plastic clip, but do not completely tighten. Reinstall the weather strip and adjust the pillar pod so that it lines up properly to the windshield. Once aligned, tighten the screw using a Phillips-Head Screwdriver.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.