

7 Gauge Replacement Cluster for 1967-1972 Chevrolet C10



1. Start by removing the Wiper Switch Knob and the Headlight Knob. Remove the trim nuts from under the knobs as well.
2. Undo the 6 Phillips head screws holding the factory Gauge Cluster on and then remove.
3. Remove the factory Gauge Cluster from the dash; make sure to undo the speedometer cable from the back of the speedometer.
4. Splice the included turn signal socket wires into the factory turn signal harness using a splice connector.
5. Install each gauge into the replacement cluster using the mounting brackets, washers, and nuts. Be sure not to overtighten the nuts as it will damage the gauges.
6. Once all of the gauges have been installed, insert the wiring harnesses into each designated gauge and push the new turn signal sockets into the turn signal locations on the back of the new Gauge Cluster.
7. Feed the opposite end of the wiring harness down through the dash and insert the new cluster into the dash. Secure using the supplied screws: the 2 black screws are for the top holes and the 4 silver screws are for the lower holes, 2 on each side.
8. Reinstall the trim nuts on the Headlamp Switch and Wiper Switch followed by the knobs.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.