

Air Vent Single Gauge Pod for 2013-2015 Subaru BRZ & Scion FR-S

1. Remove the vent housing from the dashboard.
2. With the vent housing in your hand, unclip the outer trim ring by using a small flathead screwdriver. Unclip the inner trim ring by using the screwdriver and slide out the vent diffuser.
3. Install 2 pieces of the supplied thin foam tape on the vent pod ring. Place one piece of foam tape at 9 o'clock and the other directly across at 3 o'clock. (Top Picture Shown)
4. Slide the 52mm adapter around the body of the gauge.
 - Adjustments to the adapter may be necessary by using sandpaper or a file to allow the ring to slide all the way up the gauge.
5. Place 3-4 pieces of the supplied thicker foam tape on the adapter ring and the body of the gauge.
6. Slide the gauge and adapter ring into the vent pod ring.
7. Slide the entire assembly into the vent assembly.
 - Trimming of the honeycomb inside the vent assembly may be necessary to fit the gauge all the way.
8. Reattach the inner and outer trim rings.
9. Secure all gauge connections.
10. Slide the vent assembly back into the dashboard and test the completed operation.



All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.