

Vent Gauge Pod for 1987-1993 Ford Mustang

1. Using a panel pop tool carefully remove the vent from the vent assembly above the climate control knobs.
 - You can remove either the left, right or both vents from the vent assembly.
2. Using a panel pop tool release the 4 retaining tabs holding the vent assembly and carefully remove from the dash.
3. Drill a hole in the back of the vent assembly to pass the power and sensor harnesses through. Be sure to leave enough clearance for the air flow adjustment plates to move.
4. Route the harness up through the dash and reinstall the vent assembly back into the dash.
5. Ensure that the air flow adjustment wheel is seated properly and clip the vent gauge pod into the vent assembly, temporarily slide the gauge in and test-fit the clearance inside the vent assembly.
6. Once you have confirmed that there is enough clearance, slide the gauge into the vent pod.

Note: The vent pod is designed to hold the gauge in place, if your gauge is loose or if you want to secure it, install the studs on the back of the gauge and secure with the supplied gauge bracket. Be sure **NOT TO OVERTIGHTEN** the nuts on the back of the gauge.
7. Finish installing the gauge following the gauge instructions.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.