

Vent Gauge Pod for 2002-2004 Subaru Impreza WRX

1. Carefully remove the trim around the shifter assembly by releasing the locking tabs and pulling up.
2. Using a Phillips head screwdriver, remove the 2 screws holding the radio trim into the dash.
3. Pull out the cup holder and remove the 2 screws with a Phillips head screwdriver, then remove the cup holder assembly.
4. Remove the vent assembly from the dash.
5. Remove the 2 screws from the back of the vent assembly with a Phillips head screwdriver and separate the 2 parts. Remove the vent grills.
6. Notch the bottom of the rear half of the vent assembly on both sides to ensure there is enough room for the gauge wire harnesses to pass through when the vent assembly is installed and making contact with the duct work in the dash.
7. Install the Vent Gauge Pods into the vent assembly with the lip facing outward. Clip the 2 halves of the vent assembly together and secure with the factory screws.
8. Install the gauge wiring following the gauge instructions and pass the harness through the vent assembly. Slide the vent assembly into the dash making sure to have the harness pass through the notches that were cut so they do not get pinched.
9. Reinstall the cup holder and tighten the 2 screws.
10. Reinstall the radio trim and tighten the 2 screws.
11. Reinstall the shifter trim.
12. Plug the harnesses into the gauges and place into the vent pods.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.