

Vent Gauge Pod for 2010-2014 Ford Mustang

1. Carefully pull the vent assembly out of the driver side of the dash, to the left of the steering wheel. It is held in with plastic tension clips.
2. Using a flat blade tool, carefully remove the chrome trim ring on the vent assembly by releasing the plastic tabs.
3. Remove all of the diffuser fins from the vent assembly by unclipping them.
4. Slide the gauge pod into the empty vent assembly, with the flat side towards the inside. It will only line up in that direction.
5. Carefully reinstall the chrome trim ring.
6. Mount the gauge into the gauge pod and follow the gauge installation instructions to connect the wiring and/or lines.
7. Use a panel pop tool to remove the side cover of the dash to gain access to the ductwork. Using a drill and drill bit, drill a hole in the ductwork to pass the wiring and/or lines through to where the gauge will be placed.
8. Reinstall the vent assembly into the dash and secure using the factory tension clips.
9. Reinstall the dash side cover.

All GlowShift Products are subject to the GlowShift Limited Warranty. Please visit <https://www.glowshiftdirect.com/warranty-policies> to review complete Warranty, Terms, and Conditions.